

SWITCHING SYSTEM 110




Fig. 1





FIG. 2B



TOP SECRET




FIG. 3

400 FIGURE 4 404 408 412

A	Play Review Listen to	New	messages	11
B	Play Review Listen to	Saved	messages	12
C	Delete Erase	message		337
D	Save	message		339
E	Next Skip	message		#
F	Repeat Replay	message		334
G	Envelope	Information		335
H	Forward	message		336
I	Record	a	Reply	338
J	Record	a	New Message	2
K		Options		0
L		Mark it	Urgent	2
M			Confirmation	3
N		Mark it	Private	1
O		Send	message	#
P	Main Menu			33*
Q	Cancel Finished			*
R	Pound			#
S	Star			*
T	Goodbye Hang-up Exit			***
U	Any 4 digit number - i.e. mailbox or ext.			4 digit number

BEST AVAILABLE COPY